

Video to USB adapter, Model VA11A

INSTALLATION AND OPERATING INSTRUCTIONS

IMPORTANT: Use of the VA11A Video to USB adapter requires Windows[®] 95 OSR 2.1 with USB support, Windows 98, Windows Me, Windows 2000, or Windows XP.

Note: You might need to have your Windows CD handy, in case Windows needs to install additional components.

DO NOT plug the VA11A USB adapter into your PC until you install the X10 software.

1. Download the desired software from Controlhome CD:
2. Run the installation program. Select the directory where the software will be installed, and follow the on screen instructions.
3. When the installation program instructs you to plug in the USB adapter, plug the VA11A into your USB port. Your computer will recognize that new hardware has been connected and will complete the installation.
4. Plug an XCam camera or Video Receiver (both sold separately) into the VA11A as per their instructions.

® Windows is a Registered Trademark of Microsoft Corporation.

F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

NOTE: NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.